

Determine whether SIM card has been inserted and if so

Access SIM data

Transmit SIM data to base station


Base station compares SIM data with a local copy of authorized user data  
file

If information matches, then grant mobile unit access to base station

Else indicate access failure.

If SIM card is not available, indicate access failure.

FIG. 1






FIG. 2B